



CadCamSystems

Support Document

SENTINEL DRIVERS & EXCHANGE

Exchange version 5.3 and higher require sentinel drivers Version 7.3.2 or higher.

Exchange does NOT install the sentinel driver as it is assumed to have already been installed by our other products. This means that Exchange will fail to run if older versions of the sentinel driver are currently installed. This will affect users who do not have new versions of other Delcam products installed that updated the driver during their installation.

Sentinel 7.3.2 was included on the DVD for the customer release of PowerSHAPE 7.2. Sentinel 7.3.2 was included on the CD for the customer release of PowerMILL 8.009.

For those stand-alone users of Exchange 5.3 who do not have access to recent DVD's containing the new driver, the newest version of the sentinel driver can be downloaded from our web site at the following address:

<http://www.cadcamsystemsinc.com>

Go to the Answer page and click on the link to download the driver.

This version (7.3.2) has been tested on Win XP SP2 with our latest products with no problems being found.

To clarify; a version >7.3 of the Sentinel driver is required to run Exchange 5.3

Further instructions on downloading and installing the sentinel driver can be found on the separate support document "Install sentinel driver".