

### Dongle Leash

To help you secure your dongles, we have developed a way to place a dongle inside the computer case, yet be able to unplug it when necessary for software updates.

To do this, you'll need to make a "dongle leash." The leash goes through the port cover on the case, with the female end inside and the male end outside. The dongle is plugged into the female end of the leash, with the male end plugged into the computer's usb port. **When the port cover is put in place, the dongle is inside the case, out of view and protected from theft or damage.** For a further level of security, the computer case can be locked so that the dongle can only be removed by authorized personnel. The dongle can be unplugged while still inside the case by unplugging the leash.

#### Parts needed:

3 foot extension cable

Computer port cover



Shop CDW My Account

Search for...

Products Services Solutions

All Categories > Cables > USB Cables > Belkin 3' PRO Series USB Extension Cable

**Belkin 3' PRO Series USB Extension Cable**  
Mfg. Part: F3U134B03 | CDW Part: 504368 | UNSPSC: 26121604

3' USB extender - 4 pin USB Type A (M) - 4 pin USB Type A (F)

Qty: 1 **\$3.99** Advertised Price

Add to Cart Availability: In Stock

View Photo Gallery

**Create:**

Take any computer port cover and create a hole in it a bit larger than the male end of the cable, but smaller than the female end of the cable.



The completed leash

